

MiniView

User Guide



The most economical way to control four computers from a single keyboard, monitor and mouse.

PACKING LIST

MiniView CS-14 x 1
User's Manual x 1

Check to make sure that the unit was not damaged in shipping. If you discover a problem, contact your dealer. Read the manual thoroughly, and follow the installation and operation procedures carefully in order to prevent any damage to the unit and/or any devices it connects to.

©Copyright 1999 ATEN® International Co., Ltd.
Manual Part No.CS-14 PAPE-1148-100
Printed in Taiwan

All brand names and trademarks are the registered property of their respective owners.

CONTENTS

Overview	1
Features	2
Hardware Requirements	3
Console	3
PC	3
Cables	3
Installation	4
Top View	4
Right Side View	5
CPU Port View	5
Console View	5
Operation	7
Manual Port Selection	7
Hot Key Port Selection	7
Appendix	10
Troubleshooting	10
Specifications	11
Radio & TV Interference Statement	11
Limited Warranty	12



ATEN Technology Inc.
16560 Aston Street
Irvine, CA 92606,
USA

Tel: 949-250-1260
FAX: 949-250-1262

Sales@aten-usa.com
Web: www.aten-usa.com

Entire contents copyright 1999 ATEN
All rights reserved.
Reproduction in whole or in part without permission is prohibited.
MiniView is a trademark of ATEN.
All other trademarks are the property of their respective owners.

OVERVIEW

The MiniView CPU Switch is a control unit that allows access to four PC systems from a single console (keyboard, mouse, and monitor). Before the development of the MiniView, the only way to control multiple computer configurations from a single console was through a complex and costly network system. Now, with the MiniView, you can easily access four computers in a cost effective manner.

The MiniView provides two convenient methods to access the PCs connected to the system: using the push button Selection switch located on the unit's side panel; and entering Hot Key combinations from the keyboard. Setup is fast and easy: plugging cables into their appropriate ports is all that is entailed. There is no software to configure, and no installation routines.

There is no better way to save time and money than with a MiniView installation. By allowing a single console to manage the attached PCs, the MiniView eliminates the expense of purchasing a separate keyboard, monitor, and mouse for each PC. Additionally, it saves all the extra space they would take up, and eliminates the inconvenience and wasted effort involved in constantly having to move from one PC to the other.

FEATURES

- Controls Four Computers From a Single Keyboard, Monitor and Mouse
- Supports PC (PS/2), Mac and Sun Computers*
- Keyboard and Mouse Emulation for Error Free PC Booting
- No External Power Required
- No Software Required
- Works with Virtually Any Operating System
- Built In Surge Protection
- Supports Microsoft Intellimouse and the Scrolling Wheel on Most Mice.
- Patented VSE (Video Signal Enhancement) Technology Supports Ultra High Video Resolution at 1920 x 1440 Max Resolution
- Each PC's Keyboard Settings Are Automatically Recalled
- LED Display for Easy Status Monitoring
- Save Time, Space, Power and Equipment Costs
- Hot Pluggable - Add or Remove PCs for Maintenance Without Powering Down the MiniView KVM Switch
- Supports DDC 2B

* Additional adapters must be purchased to use the MiniView with Sun or Mac computers

HARDWARE REQUIREMENTS

Console

- One VGA, SVGA, or Multisync monitor capable of the highest resolution that you will be using on any PC in the installation.
- One PS/2 mouse .
- One PS/2 style keyboard .

PC

The following equipment must be installed on each PC that is to be connected to the system:

- A VGA, SVGA or Multisync card.
- A 6-pin mini-DIN/(PS/2 style) mouse port.
- A 6-pin PS/2 style keyboard port.

Cables


Although it is possible to use standard extender cables to connect the PCs to the MiniView, for optimum signal integrity and to simplify the layout, we strongly recommend that you use the high quality CS Custom Cables (purchase separately).

Note: The keyboard and mouse cables have PS/2 style connectors at each end:

- If your PC uses a standard AT style keyboard socket, you will need an AT-to-PS/2 keyboard adapter, in order to plug the cable into the PC's keyboard port.
- The CS-14 does not support serial mice.


INSTALLATION

Top View




1. Selected LEDs:
Lights to indicate the currently selected port. Depending on the port's status, the LED may flash according to a specific pattern (see the table in the Appendix for details).
2. Port Selection Button
Pressing this pushbutton switch cycles through the four CPU ports (A→B→D→E→A, etc.), to select the active port. The Selected LED lights to indicate which port is the active one.

Left Side View:




CPU Port View:



1. Video Connector
2. PS/2 Style Keyboard Connector
3. PS/2 Style Mouse Connector


Console View:




1. Monitor Connector
2. PS/2 Style Keyboard Connector
3. PS/2 Style Mouse Connector

Before you begin, make sure that power to all the devices you will be connecting up have been turned off.

1. Plug the monitor, keyboard, and mouse into the Console port connectors of the MiniView unit.



2. Use the extender cables (as described in the Hardware Requirements section), to connect the monitor, keyboard and mouse ports of the PCs to the MiniView CPU Ports, as shown in the diagram below.



3. Turn on the power to the connected PCs.

OPERATION

Controlling four PCs on your MiniView installation from a single console could not be easier. Two port selection methods that provide instant access to any of the PCs are available:

- Manual Port Selection
- Hot Key Port Selection

Note: The MiniView Power On default is to link to Port A. If the PC attached to Port A is inactive, the monitor will be blank so it may appear as if the unit is not functioning. This is not the case. Simply use one of the Port Selection methods (described below), to switch to an active PC on Port B, D, or E.

Manual Port Selection

With Manual Port Selection, you simply press the Port Selection button on the MiniView's left panel to cycle among the computers (A→B→D→E→A, etc.). The Selected LED on the top panel lights to indicate which port is active.

Hot Key Port Selection

Hot Key navigation allows you to select the active PC directly from the keyboard, instead of having to manually select it by pressing the Port Selection button. The MiniView provides several Hot Key navigation features:

- Selecting the Active Port
- Auto Scan Mode
- Last/Next Mode

Note: All Hot Key operations begin by pressing and releasing the Alt + Ctrl + Shift combination. The combination must all be on the same side (i.e., LeftAlt+Left Ctrl+Left Shift, or Right Alt+Right Ctrl+Right Shift).

Selecting the Active Port:

Each CPU port is assigned an alpha ID (A, B, D, E). A Port ID Number is associated with each letter (see table, below). You access the PC attached to a port by specifying the Port ID Number as part of the Hot Key combination, as follows:

1. Press and release Alt+Ctrl+Shift
2. Key in the appropriate Port ID Number (1, 2, 3, or 4)
3. Press [Enter]

The Port ID numbers that correspond to the port letters are as follows:

Port Letter	Port ID Number
A	1
B	2
D	3
E	4

Auto Scan Mode:

The MiniView Auto Scan feature automatically switches between the four PCs at regular intervals so that you can monitor their activity without having to take the trouble of switching yourself. To invoke Auto Scan Mode, key in the following Hot Key combination:

1. Press and release Alt+Ctrl+Shift
2. Press and release 0 (zero)
3. Press [Enter]

APPENDIX

SELECTED LED Display:

Activity	Meaning
Off	Port is not selected.
On (Steady)	Port is connected to an active PC.
Flashing (On and Off equal)	Port is connected to an active PC and is being accessed in Auto Scan mode.
Flashing (On long; Off short)	Port is connected to an active PC and is being accessed in Last/Next mode.

Troubleshooting:

Note: If you are experiencing problems, first make sure that there are no problems with the cables, and that they are all properly connected.

Symptom	Possible Causes	What Action to Take
Pressing the Hot Keys gets no response.**	The CS-14 MiniView may be operating in Auto-Scan Mode. The Selected Port connects to a Powered-Off computer. Incorrectly inputting the Hot Key command.	Press the Space Bar to exit Auto-Scan Mode and retry the Hot Key command. Change the port manually using the Selection Button (pressed the Hot Key command selecting an active port or reuse). Press each key of the Hot Key sequence individually: <Ctrl> then <Shift> then <Alt> then the # and then <Enter>.
Mouse is not being detected or fails to respond correctly**	Incorrect installation of the cables. Incorrect use of adapters. Incorrect Mouse Drivers.	Make sure that all cables are firmly plugged into the mouse ports of the PCs and the MiniView unit. No adapters can be used with the mouse connections of the MiniView Unit. This unit is designed to work only with PCs using PS/2 Mice. You can not convert a PS/2 mouse signal to a Serial Mouse signal simply by using an adapter. When using any PS/2 pointing device you must ensure that the proper device driver has been loaded into your PC's operating system. Please check your Device Manager and make sure that the Manufacturer's Driver or the Operating System's driver for your mouse has been installed.

Symptom	Possible Causes	What Action to Take
No Video Image or Low Quality Video Image	Loose VGA Connection Incorrect Video Driver	Remove and reconnect the VGA connectors between the PC and the MiniView, and the MiniView and the monitor. Ensure that the connections are firmly seated and fully connected. Check the Device Manager of your operating system and make sure that the correct video adapter drivers are installed for your video card.
Keyboard Not Responding**	Loose Keyboard Connection	Check all keyboard connections to ensure that they are firmly seated and fully connected.

* The MiniView is designed to work with PS/2 keyboards. Older XT (84 key) and some older AT keyboards (those with the function keys on the side), will not work.

** Some Notebook computers, notably the IBM Thinkpad and Toshiba Tecra, have trouble working with the Master View CS-14 when their mouse and keyboard ports are used simultaneously. To avoid this problem, only connect the mouse port or the keyboard port to the Master View unit. If you connect the mouse port, you will need to use the notebook's keyboard when the notebook becomes the active computer.

Specifications:

Power Consumption	DC 5V 20mA (max)
PC Connections	4
Port Selection	Pushbutton Switch
Hot Keys	Hot Keys
LEDs	1 x power, 4 x Selected
Connectors	Keyboard 1 x 6 pin mini-DIN female (PS/2 style) - Console Mouse 1 x 6 pin mini-DIN female (PS/2 style) - Console 1 x 6 pin mini-DIN female (PS/2 style) - CPU Ports 1 x HDDB-15 female (std. VGA/SVGA) - Console 4 x HDDB-15 male (std. VGA/SVGA) - CPU Ports
Operating Temperature	5 ~ 40°C
Storage Temperature	-20 ~ 60°C
Humidity	0 ~ 80% RH, Noncondensing
Enclosure	Plastic
Weight	250g
Dimensions (L x W x H)	170 x 87 x 28.5 mm

Radio & TV Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Limited Warranty

IN NO EVENT SHALL THE DIRECT VENDOR'S LIABILITY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, DISK OR ITS DOCUMENTATION EXCEED THE PRICE PAID FOR THE PRODUCT.

The direct vendor makes no warranty or representation, expressed, implied, or statutory with respect to the contents or use of this documentation, and especially disclaims its quality, performance, merchantability, or fitness for any particular purpose.

The direct vendor also reserves the right to revise or update the device or documentation without obligation to notify any individual or entity of such revisions, or updates. For further inquiries please contact your direct vendor.