
1. Right-click on EzUtility-setup_V4.01.exe and tick 'Run this program as an administrator' in the pop-up menu. Complete the installation by double-clicking on the EzUtility-setup_V4.01.exe.






2. After successful installation, please also right-click on the shortcut icon of Ez Utility on the desktop and tick 'Run this program as an administrator' in the pop-up menu.




3. Connect the scanner and the host with cable.


4. Run Ez Utility, select "General" as genre, select "USB", "RS232" or "PS2" according to the interface of your product and click [Save Home (H)] to continue.



5. Click the Down Arrow icon on the Toolbar to retrieve configurations from the scanner.



6. Double click on desired parameters to edit and the press [Enter] to save changes.



7. Click the Up Arrow on the Toolbar to upload configuration to the scanner and you are done!

